

## VERIFY ALL VOLTAGE & AMPERAGE INFO LISTED BELOW, WITH THE ACTUAL LABEL SPECIFICATIONS ON YOUR UNIT.

MODEL NO.	ECO3.5POU	ECO5.5POU	ECO277POU
Max kW	3.5kW	5.5kW	5.5kW
Volts	110V	220V	277V
Max power	29A	25A	20A

#### WIRE GAUGE AND BREAKER SIZE CAN VARY BASED ON A NUMBER OF FACTORS INCLUDING SUPPLIED VOLTAGE AND LENGTH OF CIRCUIT CHECK LOCAL REQUIREMENTS.

MODEL	Required breaber	Max power	AWG
ECO3.5POU	ONE 30AMP	29AMPS	#10
ECO5.5POU	ONE 30AMP	25AMPS	#10
ECO277POU	ONE25AMP	20AMPS	#10

NOTES:

#### **ECOSMART US LLC**

3315 NW 167th Street
Miami Gardens, Florida 33056
WWW.ECOSMARTUS.COM

Tel: 305-623-7900 Fax: 305-623-7923 Toll Free:877-474-6473

Page 3

# YOUR ELECTRICAL WATER HEATER EXPERT



- INSTANT HOT WATER
- EASY INSTALLATION

# TANKLESS WATER HEATER

"NO TANK, NO WAIT, NO COMPARISON"

"THE MOST ADVANCED TANKLESS WATER HEATER
IN TODAY'S MARKET"



#### IMPORTANT SAFETY INFORMATION

As when installing or using any high voltage electrical appliance, basic safety precautions should always be followed. Under no circumstances should you attempt to clean, install, inspect, repair, disassemble ,or otherwise service this water heater without first shutting off all power to the unit directly at the breaker box.

SERIOUS BODILY INJURY OR DEATH COULD OCCUR IF YOU IGNORE THIS WARNING.FAILURE TO DO SO COULD CAUSE PROPERTY DAMAGE OR SERIOUS PERSONAL INJURY OR DEATH, AND VOID YOUR WARRANTY. THIS WATER HEATER MUST BE INSTALLED BY A LICENSED ELECTRICIAN AND PLUMBER PROOF OF INSTALLATION MUST ACOMPANY THE WARRANTY CARD.

#### PLEASE FOLLOW ALL RECOMMENDATIONS AND LOCAL CODE REQUIREMENTS.

FAILURE TO FOLLOW PROPER PROCEDURE IS
HAZARDOUS. IT CAN ALSO DAMAGE THE HEATER AND
VOID THE WARRANTY.

### TURN OFF ELECTRICAL SUPPLY MAIN AND WATER SUPPLY BEFORE ATTEMPTING ANY INSTALLATION!

## DO NOT TURN ON ELECTRIC OR WATER SUPPLY UNTIL INSTALLATION IS PROPERLY COMPLETED.

- DO NOT remove the heater cover, open the unit or break the seal. This could cause
   DEATH OR INJURY and will VOID THE WARRANTY.
- DO NOT Install Heater, in a shower or any where it can bell reached or adjusted by anyone while using water.
- DO NOT Operate the unit if water ceases to flow during use. Contact technical support for this or any other issue of concern, On the web at:


#### WWW.ECOSMARTUS.COM

Call:305-623-7900 or 877-474-6473

- Although installation is simple, DO have a licensed Plumber & Electrician perform the installation.
- COMPLY WITH LOCAL CODES AND PERMITTING!

#### PART IDENTIFICATION


- ①Cold water Inlet
- 2 Hot water outlet
- ③ Wire
- (4) Setting Temp. Display
- **⑤** POWER KNOB & Temp. Controller



Page 1



#### **PLUMBING**



This water heater is supplied with 1/2" compression fittings, Do not weld or use Teflon or paste.


Connect the cold water supply line to the right hand side.

Connect the hot water supply line to the left hand side.

Once both water lines are fastened and secured you must run water through the unit for at least 2 to 3 minutes to flush any air pockets(purging) in the lines, it is recommended that all faucets, showers etc be run. Failure to follow this step can cause permanent damage to the unit. This procedure MUST be performed before any electrical power is turned on.

#### **ELECTRICAL CONNECTION**

The electrical installation is based on the different Models Unit must be installed to independent breakers as per Model specs.



#### **HOW TO USE**

1.click the power button, and turn on the unit.




reducing the flow rated thus increasing the outlet temperature.


Increasing the flow rate thus reducing the outlet temperature.





## 8.9inches

# **HOW TO INSTALL**









# THE UNIT MUST NOT BE OPENED TO PERFORM THIS INSTALL OR WARRANTY WILL BE NULL AND VOID